



ASSEMBLY INSTRUCTIONS:

1. PREPARE TAPS AND CASE -- PAINT AND/OR TAPE TAPS TO PROTECT FINISH; PAINT INSIDE OF JACKET TO INHIBIT FOULING.
2. INSTALL JACKETS OVER TAPS AS SHOWN.
3. INSTALL HOSE-CLAMPS IN (3) GROOVES AND TIGHTEN JUST UNTIL JACKET IS SNUG. DO NOT OVER-TIGHTEN.
4. INSTALL EAR PROTECTORS IN PAIRS OVER TABS. CLAMP WITH SCREWS (3/8" X 1" SS) TO RETAIN.
5. PAINT EXTERIOR AS REQUIRED TO INHIBIT GROWTH.

TAPS-6 PROTECTIVE JACKET ASS'Y DWG

DATE: 981202

DWG: T6710

REV: 0

